



**NOTES**

1. AVECC RECOMMENDS THAT A LICENSED ELECTRICIAN INSTALLS TRANSFER SWITCH AND GENERATOR PER NEC CODE AND LOCAL ORDINANCES.
2. MULTIPLE CIRCUIT BREAKERS/FUSED DISCONNECTS CAN BE CONNECTED AFTER THE TRANSFER SWITCH, SO LONG AS THE SUM OF THE BREAKER INTERRUPTING CURRENT OF EACH BREAKER/FUSED DISCONNECT DOES NOT EXCEED THE AUTOMATIC TRANSFER SWITCH RATING OR THE ELECTRIC SERVICE SIZE.
3. REFER TO DRAWINGS SPEC-000001 THROUGH SPEC-0000017 FOR INCOMING SERVICE REQUIREMENTS, AVECC SUPPLIED EQUIPMENT & SERVICES, MEMBER REQUIRED EQUIPMENT & SERVICES, DITCH REQUIREMENTS, ETC.
4. WHERE PANELS AND EQUIPMENT ARE NOT MOUNTED ON BUILDING STRUCTURE, REFER TO DRAWINGS SPEC-0000011 & SPEC-0000012 FOR RACK MATERIAL AND INSTALLATION REQUIREMENTS. ALLOW ADEQUATE ROOM ON RACK FOR ALL EQUIPMENT/PANELS NECESSARY.
5. ALL EXTERIOR PANELS ARE TO BE RATED NO LESS THAN NEMA 3R.
6. PROTECTIVE BUSHINGS REQUIRED ON ALL CONDUITS.
7. NO WIRING GUTTERS OR TROUGHS WILL BE ALLOWED ON THE OUTSIDE OF THE BUILDING.
8. REFER TO DRAWING SPEC-0000012 FOR OVERHEAD CT INSTALLATION REQUIREMENTS.
9. THE SERVICE ENTRANCE DISCONNECT MEANS SHALL BE INSTALLED AT A READILY ACCESSIBLE OUTDOOR LOCATION. IF MORE THAN ONE DISCONNECTING MEANS ARE PROVIDED THEY SHALL BE GROUPED PER NEC 230.85.
10. IF THE GROUND WIRE IS EXPOSED TO PHYSICAL DAMAGE THE WIRE SHALL BE PROTECTED BY CONDUIT PER NEC 250.64(B)(2).
11. ONLY THE COOPERATIVE'S CONDUCTORS AND MEMBERS SERVICE ENTRANCE CONDUCTORS ALLOWED IN METER BASE. METER BASE CANNOT BE USED AS A PASS THROUGH FOR OTHER CONDUCTORS. REFER TO SPEC-0000004 FOR METER BASE CONDUCTOR CONNECTION DETAIL.
12. POWER SUPPLY AFTER THE MAIN DISCONNECT SHALL BE A 4 WIRE SYSTEM INCLUDING A GROUNDING WIRE AND NEUTRAL WIRE. THE SERVICE SHALL MEET ALL NEC REQUIREMENTS.



**ARKANSAS VALLEY ELECTRIC  
COOPERATIVE COOPERATION**

TITLE		
OH 600A STANDBY GENERATOR, PARTIAL SERVICE AUTOMATIC TRANSFER SWITCH		
DWG#: SPEC-0000030	DATE: 12.08.2017	SCALE: NTS
DRAWN BY: JDC	REV: 1	REV. DATE: 5.09.23